

For high pressure washer with petrol, Diesel or electric engine

MAIN FEATURES

- ▶ Pressure safety
- ▶ Automatic Start/Stop

Automatic Start/Stop pressing the trigger of the spray gun, the circulation of water automatically triggers the burner, and it stops when releasing the trigger.



UTILISATION

- 1) Connect the high pressure washer to the water mains.
- 2) Connect the HP washer to the generator thanks to the hose supplied.
- 3) Connect the HP hose and the lance on the outlet of the generator.
- 4) Turn the generator on
- 5) Set the temperature thanks to the generator's thermostat.
- 6) Start the high pressure washer.

SPECIFICATIONS

- Engine : 220 V single phase electric engine
- Electric cable : 5 m
- Boiler : steel coil
- Fuel oil burner
- Thermostat : for temperature regulation
- Fuel tank capacity : 35 l
- Valve : pressure safety
- Pressure switch : pressure safety
- Flow switch : lack of water safety
- Frame : paint steel
- Hood : stainless steel AISI 430
- Rubber-tyred wheels
- Swivel castor : with break

STANDARD EQUIPMENT

- Connection hose : 3 m special high pressure hose between HP washer and generator

MODEL



REFERENCE	FOR HP WASHER			TEMPERATURE °C	WEIGHT kg
	MAX. FLOW RATE		PRESSURE		
	l/min	l/h	bar		
AQUA PREMIUM	21	1260	250 max.	60/90 <i>Depending on the flow of the cleaner</i>	116